

BENZING Printer Converter

Easy Manual

Step 1 Connect the Printer Converter to the LPT port of the BENZING ClubSystem

In order to use the BENZING Printer Converter with one of your USB printers, be sure that you follow each step:

Note: The Printer Converter is only working with some printer languages. (Mostly this is described within the printer manual)

Working	Not working
PCL1	PCL 1+
PCL2	PCL 3+
PCL3	PCL 3c+
PCL4	PCL 3GUI
PCL5	PCL 5e
PCL6	PCL 5c



Step 2 Connect the power plug to the BENZING ClubSystem

Within the Printer Converter package, there is a special power cable for connecting this system to the BENZING ClubSystem. At the BENZING ClubSystem you can choose one of the two PMDIN sockets - for instance the PMDIN socket like shown in the picture below.

If you would like to connect a BENZING clock to the ClubSystem after everything is set up, than you can already hook up the BENZING ClubSystem cable to the system.



Step 3 Connect the power plug and USB cable

Make sure that the BENZING ClubSystem is powered on (see the description of the BENZING ClubSystem). Now connect the power plug of the special power cable to the socket of the Printer Converter.

Connect the USB cable of the USB-printer to the Printer Converter.



Step 4 Power up your USB printer and print out the sheets

Press the power button of your printer, in order to power it up. The printer converter will now search the device; this could take up to 1 minute.

Now you are ready to print lists out of the BENZING clock.

